

# HES PV

# **Accessories**

## **Conduit Box**



The ME-CB conduit box is designed to work with Magnum ME, MS, and RD Series Inverter/Chargers. It provides an enclosure for AC and/or DC wiring and has knockouts for ½", ¾", 1", and 2" trade-size conduit. The ME-CB adds just over 5" (13 cm) to the length of the inverter.

#### **MODEL NUMBERS**

ME-CB

#### **WORKS WITH**

- ME Series
- MS Series
- MS-AE Series
- RD Series
- RD-E Series

# **DC Load Disconnect**

The DC Load Disconnect is a pigtail adapter designed to automatically turn off the inverter via a 12 volt DC disconnect switch.

## **MODEL NUMBERS**

■ ME-DCLD

### **WORKS WITH**

- ME Series
- MS Series
- MS-AE Series
- RD Series
- RD-E Series

#### **Fuse Blocks**



**Protection against costly** damage: The ME-125F, ME-200F, ME-300F, and ME-400F protect the battery bank, inverter, and cables from damage caused by short circuits and overloads.

# Complete kit in one package:

Magnum Energy fuses include a Slow-Blow high current fuse, a mounting block, and protective cover.

# MODEL NUMBERS

- ME-125F
- ME-200F
- ME-300F
- ME-400F

# **WORKS WITH**

## ME-125F and ME-200 only

- MM Series
- MM-AE Series
- MMS Series
- MM-E Series

# ME-300F and ME-400F only

- ME Series
- MS Series
- MS-AE Series
- RD Series
- RD-E Series

**Fuse Selection** 

| <b>Conductor Gauge</b> | <b>Current Capacity</b> | <b>Recommended Fuse Rating</b> |
|------------------------|-------------------------|--------------------------------|
| 4 AWG                  | 125                     | 125                            |
| 1/0 AWG                | 200                     | 200                            |
| 2/0 AWG                | 290                     | 300                            |
| 3/0 AWG                | 310                     | 300                            |
| 4/0 AWG                | 360                     | 400                            |

The Powerful Difference



# **Accessories**

# **Ignition Switch Lockout**

The Ignition Switch Lockout is a pigtail adapter designed to automatically turn off the inverter via a vehicle ignition switch.

## **MODEL NUMBERS**

ME-ISW

#### **WORKS WITH**

- ME Series
- MS Series
- MS-AE Series
- RD Series
- RD-E Series

# **Remote Switch Adapter**



The Remote Switch Adapter is a pigtail adapter designed to provide a simple on/off remote switch.

## **MODEL NUMBERS**

- ME-RSA
  (use SPST switch)
- ME-RSA-M


(use momentary switch)

#### **WORKS WITH**

- ME Series
- MS Series
- MS-AE Series
- RD Series
- RD-E Series

# **Series Stacking Cable Kit**





The Series Stacking Cable Kit allows two inverters to be stacked together to achieve 120/240 VAC output. Series stacking is commonly used for well pumps, tools, motors, and other 240 VAC appliances. The kit includes communication cable, two 2/0 battery cables, and battery lug covers.

#### **MODEL NUMBERS**

ME-SSI

#### **WORKS WITH**

■ MS4024

